HD-44G

4x4 HDMI MATRIX SWITCHER

INSTRUCTION MANUAL



A-NEUVIDEO®

AUDIO / VIDEO MANUFACTURER

A-NeuVideo.com | Frisco, Texas 75034 | (317) 456-2461

SAFETY INFORMATION

1. To ensure the best results from this product, please read this manual and all other documentation before operating your equipment. Retain all documentation for future reference.
2. Follow all instructions printed on unit chassis for proper operation.
3. To reduce the risk of fire, do not spill water or other liquids into or on the unit, or operate the unit while standing in liquid.
4. Make sure power outlets conform to the power requirements listed on the back of the unit. Keep unit protected from rain, water and excessive moisture.
5. Do not attempt to clean the unit with chemical solvents or aerosol cleaners, as this may damage the unit. Dust with a clean dry cloth.
6. Do not use the unit if the electrical power cord is frayed or broken. The power supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords and plugs, convenience receptacles, and the point where they exit from the appliance.
7. Do not force switched or external connections in any way. They should all connect easily, without needing to be forced.
8. Always operate the unit with the AC ground wire connected to the electrical system ground. Precautions should be taken so that the means of grounding of a piece of equipment is not defeated.
9. AC voltage must be correct and the same as that printed on the rear of the unit. Damage caused by connection to improper AC voltage is not covered by any warranty.
10. Turn power off and disconnect unit from AC current before making connections.
11. Never hold a power switch in the “ON” position.
12. This unit should be installed in a cool dry place, away from sources of excessive heat, vibration, dust, moisture and cold. Do not use the unit near stoves, heat registers, radiators, or other heat producing devices.
13. Do not block fan intake or exhaust ports. Do not operate equipment on a surface or in an environment which may impede the normal flow of air around the unit, such as a bed, rug, carpet, or completely enclosed rack. If the unit is used in an extremely dusty or smoky environment, the unit should be periodically “blown free” of foreign dust and matter.
14. To reduce the risk of electric shock, do not remove the cover. There are no user serviceable parts inside. Refer all servicing to qualified service personnel. There are no user serviceable parts inside.
15. When moving the unit, disconnect input ports first, then remove the power cable; finally, disconnect the interconnecting cables to other devices.
16. Do not drive the inputs with a signal level greater than that required to drive equipment to full output.
17. The equipment power cord should be unplugged from the outlet when left unused for a long period of time.
18. Save the carton and packing material even if the equipment has arrived in good condition. Should you ever need to ship the unit, use only the original factory packing.
19. Service Information Equipment should be serviced by qualifier service personnel when:
    A. The power supply cord or the plug has been damaged.
    B. Objects have fallen, or liquid has been spilled into the equipment.
    C. The equipment has been exposed to rain
    D. The equipment does not appear to operate normally, or exhibits a marked change in performance
    E. The equipment has been dropped, or the enclosure damaged.

TABLE OF CONTENTS

CONTENTS

INTRODUCTION & PACKAGE CONTENTS 1
FEATURES & SPECIFICATIONS 2
FRONT PANEL 3
REAR PANEL 6
TYPICAL APPLICATION 7
REMOTE CONTROL 9
IR EXTENDER 11
EDID FUNCTION 13
RS-232 SERIAL INTERFACE 16

INTRODUCTION

The HD-44G is professional 4x4 matrix routing switch. Supporting (4) HDMI Inputs. Output supported (4) HDMI. The HD-44G is based on the HDMI standard and supports full resolution HDMI Video with embedded EDID. With a signal bandwidth of 340Mhz, there is no signal degradation. High Definition Digital signals can be selected and distributed from any (4) Inputs to any (4) Outputs in any combination. The Switcher is certified as being fully CEC and HDCP 2.0 compliant, full HD HDMI V1.4a 3D formats, data rates up to 6.75 Gbps. Supports UXGA/WUXGA/DVI 1920x1200 resolution to any HD displays. The Switcher is certified as being fully HDMI and HDCP compliant, with RoHS, CE, FCC certification. Support high resolution HDMI sources routed to HDMI displays, monitors, projector or audio receivers. The EDID management can be selected between (7) different modes. Control is provided via Front panel push buttons, IR remote, RS-232 or TCP/IP (not a web-browser). An RS-232 Windows GUI interface is provided for matrix routing control (Windows only).

PACKAGE CONTENTS

Before attempting to use this unit, please check the packaging and make sure the following items are contained in the shipping carton:

- Main switch console unit
- RS-232 V2.0 Protocol Instructions
- Ethernet V2.0 Protocol Instructions
- Master wireless IR Remote Control (SW-HD44)
- 19 inch Ear mount bracket (Part # 1U-440L)
- IR RX-100 IR Receiver Extender distance ~ 984ft (300M) Receiver set
- CD Contents : Windows GUI, ISP V1.0 Windows driver
- RS-232 Cable 6 ft (2M)
- ISO Screws
- Operating Instructions
- Worldwide Universal Power Supply: DC12V, 5A, (Worldwide Universal 100~240 VAC, AC 50/60Hz.)

SAFETY PRECAUTIONS

Please read all instructions before attempting to unpack, install or operate this equipment and before connecting the power supply. Please keep the following in mind as you unpack and install this equipment:

- Always follow basic safety precautions to reduce the risk of fire, electrical shock and injury to persons.
- To prevent fire or shock hazard, do not expose the unit to rain, moisture or install this product near water.
- Never spill liquid of any kind on or into this product.
- Never push an object of any kind into this product through any openings or empty slots in the unit, as you may damage parts inside the unit.
- Do not attach the power supply cabling to building surfaces.
- Use only the supplied power supply unit (PSU). Do not use the PSU if it is damaged.
- Do not allow anything to rest on the power cabling or allow any weight to be placed upon it or any person walk on it.
- To protect the unit from overheating, do not block any vents or openings in the unit housing that provide ventilation and allow for sufficient space for air to circulate around the unit.

DISCLAIMERS

The information in this manual has been carefully checked and is believed to be accurate. We assume no responsibility for any infringements of patents or other rights of third parties which may result from its use.

We assume no responsibility for any inaccuracies that may be contained in this document. We make no commitment to update or to keep current the information contained in this document.

We reserve the right to make improvements to this document and/or product at any time and without notice.

COPYRIGHT NOTICE

No part of this document may be reproduced, transmitted, transcribed, stored in a retrieval system, or any of its part translated into any language or computer file, in any form or by any means — electronic, mechanical, magnetic, optical, chemical, manual, or otherwise — without express written permission and consent

© Copyright 2015. All Rights Reserved.

Version 1.1 JAN 2015

TRADEMARK ACKNOWLEDGMENTS

All products or service names mentioned in this document may be trademarks of the companies with which they are associated.

FEATURES

FEATURES

- 4x HDMI digital source devices matrix switched to 4x HDMI devices
- HDMI digital video w/embedded audio, DVI format and CEC/HDCP 2.0 compliant
- (7) function key control and worldwide EDID modes for HDTV resolutions
- Link speeds of up to 6.75 Gbps (link clock rate of 225Mb Hz), Support HDMI 1.4a 3D formats
- Wide range of HD resolutions from PC XGA to WUXGA 1920x1200 and HDTV/DTV resolutions 480i/480p, 576i/576p, 720p, 1080i & 1080p
- Compatible with all HDMI source devices, PC monitors, Plasma HD display, HDTV and audio receivers/amplifiers
- Digital Video TMDS formats Resolution up to 1080p-60 with Deep color 36-bit
- Digital Audio Support : Dolby TrueHD, Dolby Digital, Dolby Digital Plug/ex, DTS, DTS-HD, DTS-HD Master, DTS-EX, PCM, PCM2, LPCM2
- Various User Interface control:
    - Windows based GUI control via RS-232 port
    - Front Panel push button
    - IR wireless remote control
    - Third party RS-232 controller (via simple ASCII)
- Supports world wide control functions: ALL/OFF/RECALL/ENTER/MEMORY/EDID/LOCK
- Supports EDID modes :
    - Embedded EDID modes : FSS/H24-3D/H24-3D-M/H36-3D/H36-3D-M/DVI-D 1280x1024-60Hz/DVI-D 1920x1200-60Hz
    - External modes : Learning mode
- Automatic scanning input & output status via LCM show on front panel
- Supports IR Remote and IR Extender with distance up to ~ 984 ft (300M) Maximum
- EDID configuration via Internal modes
- Consumer Electronic Control (CEC) switch all open or OFF

The Switcher will remember that last state during a power cycle. When power is removed and resorted, the last configuration will be invoked.

SPECIFICATIONS

- **Type of Switcher:** 4x HDMI Inputs to 4x HDMI Outputs Matrix Switcher
- **HDMI Support:** HD 1080p@60Hz, H36-bit Deep color, 3D (1.4a) formats
- **HDCP / CEC Support:** HDCP 2.0 Compliant, CEC Compliant
- **Video Bandwidth:** Double Data Rates: 225Mhz, Total 6.75Gbps bandwidth
- **Digital Video Support:** Full HD Resolution : 480i / 480p / 720p / 1080i / 1080p
- **Digital Audio Support :** Multi Audio Formats 5.1 / 7.1, MAT(MLP), Dolby Digital, Dolby TrueHD, Dolby Digital Plus, DTS, DTS-ES 6.1, DTS-HD, DTS-HD-HRA, DTS-HD Master, (PCM-2CH)
- **Controls:**
    - 1x IR Remote Controller
    - 1x IR External port x1 (OD 3.5mm Ear phone Jack)
    - 1x Select & Function buttons on front panel
    - 1x RS-232 series interface
- **Source Status:** Automatically Scan Sources Inputs via LED
- **Function Keys:** ALL / OFF / RECALL / ENTER / MEMORY / LOCK / EDID
- **Infrared Frequency:** 38 Khz
- **IR External Distance:** ~984 ft / 300 m maximum
- **HDMI I/O Connector:** HDMI Type A - SMD 19pin Female Type
- **Temperature:** 32 °F - 100 °F Operation (0 °C - 32 °C)
- **Dimensions (LxWxH):** 19 x 9.85 x 1.75 in (482x250x44 mm)
- **Rack Mount:** 1RU High 19 in (with rack mount)
- **Power Supply:** DC12V / 3A, Universal world wide Type 50/60Hz, 100~230 VAC
- **Power Consumption:** 2150 mA Maximum
- **Safety Approvals:** CE, FCC, RoHS (2002/95/EC)
- **Product Weight:** 1.85 Kg / 3.08 lb

As product improvements are continuous, specifications are subject to change without notice.

FRONT PANEL

FRONT PANEL



1 POWER SWITCH:
The power switch turns the unit on and off. The LED will illuminate red to indicate that the switcher is ON and is receiving power.
The Switcher will remember that last state during a power cycle.
When power is removed and resorted, the last configuration will be evoked.

---

2 INPUT STATUS DISPLAY:
Input sources (1) to (4) LCM illuminates blue to indicate that a video source is present on that input.

---

3 OUTPUT STATUS DISPLAY:
Each Output (destination) Channel shows which input (source) is assigned.

---

4 DESTINATION SELECT BUTTONS:
Separate outputs (1) thru (4) select buttons are provided for each destination assignment. Routing can be Source to Destination or one source to multiple destinations. *Example : Press Destination 1,2,4 then press Source 2 will route Input 2 to Output 1,2,4 respectfully.*

---

5 EDID MODE SELECT BUTTONS: Used to select EDID mode using Input buttons #1 and #2.

---

6 IR SENSOR: The IR sensor receives IR commands from the supplied remote controller or third party IR emitter.

---

7 SOURCE SELECT BUTTONS: Separate inputs (1) thru (4) select buttons are provided each source selection.

---

8 FUNCTION KEY - ALL

Disables (mute) video on all destinations OR Selects the same source to all destinations.

Option 1
- Press **ALL** followed by **OFF** button. The display will show " 0 " indicating all destinations have no video selected.

Option 2
- Press **ALL** followed by Source 1 thru 4. The display will show the Source selected.
- Press **ENTER** The pre-set source selection will be assigned all destinations.

FRONT PANEL

FRONT PANEL



9 FUNCTION KEY - OFF

Disables (mute) video to selected channels. Either destinations.

- Press **OFF** button followed by any Destination channel.
- Press 1 thru 4 output destination. The display will show ” 0 “ for the selected channel indicating no video selected.

---

10 FUNCTION KEY - RECALL

The system will show previously stored presets, up to a total of 8. Presets are stored in local memory using Source keys 1 thru 4 or Destination keys 1 thru 4 as the memory preset location.

- Press **RECALL** button.
- Press 1 thru 4 on either Source or Destination row.
- Press **ENTER** The pre-set configuration will execute.

Operation completes.

Note : Operation will abort if no keys are pressed within 5 seconds.

---

11 FUNCTION KEY - ENTER

Press **ENTER** to confirm entries.

FRONT PANEL

FRONT PANEL



12 FUNCTION KEY - MEMORY

The system will show store presets, up to a total of (8). Presets are stored in local memory using Source keys 1 thru 4 or Destination keys 1 thru 4 as the memory preset location.

- Configure desired matrices..
- Press **MEMORY** button.
- Press 1 thru 4 on either Source or Destination row.
- Press **ENTER** to ready memory location.
- Or press **MEMORY** again to cancel operation.

Operation completes.

Note : Operation will abort if no keys are pressed within 5 seconds.

---

13 FUNCTION KEY - LOCK

- Press and hold **LOCK** button for two seconds lockout the front panel.
- Press and hold **LOCK** button for two seconds to enable the front panel.

---

14 FUNCTION KEY - EDID

- Press **EDID** to select new EDID mode or select source row #1 or #2 for LINK source EDID again.

---

15 19 INCH EAR MOUNT PAIR

Converts desktop to 19 inch rack mount. Bracket (part # 1U-440L) INCLUDED. Image shows rack mount bracket attached.

REAR PANEL

REAR PANEL



1 DC POWER INLET

The Switcher is fitted with a DC power plug input connector. Ensure that the used is of an approved type and is of sufficient current carrying connector capacity with the correct voltage and connector polarity. 12Volt DC power supply 3A Max (Center pin positive).

Power Jack:
DC Jack - Inner OD ⦰ 2.1mm (+)
Outside OD ⦰ 5.5mm (GND)
Power input - 12VDC, 3A

---

2 IR EXTENDER CONTROL

Support one of IR Extender. Extend distance maximum 300 Meters / ~984 feet. When you plug the External IR extender into the switcher, the front panel IR receiver remain active.

IR Extender Jack:
Female Jack - inner OD ⦰ 3.5 mm

---

3 RS-232 CONNECTION

RS-232 control port to allow for interfacing to a PC a computer or touch panel control, to the switcher via this DB-9pin Female connector for serial RS-232 control.



Remote port :
D-SUB-9pin Female connector

---

4 INPUTS- 1,2,3, & 4 HDMI

Connect a signal link of HDMI direct digital video/audio to this Female HDMI connector. This connector supports HDMI digital video/audio and DVI digital video sources.

HDMI Digital Video/Audio, Connector with fix screw
Input 1 ~ Input 4



HDMI Digital Video/Audio Connector:
HDMI Female connector.

Note: With the proper adapters, the switcher can be used with DVI digital video signals HDCP compliant. DVI does not support audio.

---

5 OUTPUTS- 1,2,3,& 4 HDMI

Connect a signal link of HDMI direct digital video/audio to this Female HDMI connector. This connector supports HDMI digital video/audio and DVI digital video sources.

HDMI Digital Video/Audio, Connector with fix screw
Output 1 ~ Output 4



HDMI Digital Video/Audio Connector:
HDMI Female connector.

Note: With the proper adapters, the switcher can be used with DVI digital video signals HDCP compliant. DVI does not support audio.

TYPICAL APPLICATION

INSTALLING DIAGRAM

Sample connection using RS-232 serial interface or IR External in to control switch (HD-44G).



NOTE:

1. Control Projector Over CAT5e/6/7 Extender:
   HD-6335T: HDBaseT™ HDMI CAT5e/6/7 Transmitter
   HD-6335R: HDBaseT™ HDMI CAT5e/6/7 Receiver
2. Preview Output : Picture as same OUTPUT-1
3. RS-232 Control
4. External IR Remote.
5. IR Extender Transmitter : IRTX-101 : IR Extender Transmitter
6. IR Extender Receiver : IR RX-100 : IR Extender Receiver.

Support HDBaseT™ Extender by HDBaseT™ Transmitter and Receiver via CAT5e/6/7 cable

TYPICAL APPLICATION

INSTALLING DIAGRAM

Sample connection using Audio Extractor to Audio Amplifier and ARC Control Box link TV Return Audio to Audio Device, Control a Satellite Receiver source via HDBaseT™ Transmitter (HD-6335T) and HDBaseT™ Receiver (HD-6335R).

NOTE:

1. Control Satellite Receiver Over HDMI CAT5e/6/7 Extender from room:
   HD-6335T: HDBaseT™ HDMI Transmitter
   HD-6335R: HDBaseT™ HDMI Receiver
2. Audio Extractor To Recode Audio :
   HD-5609: HDMI Audio Extractor.
3. Control HDMI ARC:
   HD-5610: HDTV ARC Control Box.
4. IR Extender Transmitter :
   IRTX-101: IR Extender Transmitter.
5. IR Extender Receiver :
   IR RX-100: IR Extender Receiver.



Support HDBaseT™ Extender by HDBaseT™ Transmitter and HDBaseT™ Receiver via CAT5e/6/7 cable

REMOTE CONTROL

Before making any connections to the switcher. Observe the following:

> Ensure the mains voltage supply matches the label on the supplied plug-pack (+/- 10%)
> Ensure that the power switch is OFF
> Ensure that all system grounds (earth) are connected to a common point.
> Avoid powering equipment within a system from multiple power sources that may be separated by large distances
> Connect all audio video sources and destination equipment
> Power up all source and destination audio-visual sources
> For each destination output select the appropriate input source by using the front panel input 1~4 select buttons. The supplied IR remote control. Or through the RS-232 serial communications port.
> Upon power up the switcher will return to its last used setting before powered down.

IR REMOTE CONTROL KEY

1 2 SWITCH POWER ON or OFF
Controller with a separate power ON and OFF

3 DESTINATION : 1 thru 4 OUTPUT SELECTION
Press the destination button to select the output display channel.

4 SOURCE : 1 thru 4 INPUT SOURCE SELECTION
Press input 1~ 4 sources with selection button

5 FUNCTION KEY
ALL - function selection button
DEMO or ENTER - function selection button
EDID - function selection button
LOCK - function selection button

6 SELECT EDID MODES : press source button 1 thru 2.
1. Mode 1 : FSS (Fast Speed Start)
2. Mode 2 : H24-3D
3. Mode 3 : H24M-3D
4. Mode 4 : H36
5. Mode 5 : H36M
6. Mode 6 : H36-3D
7. Mode 7 : H36M-3D



REMOTE CONTROL

IR REMOTE CUSTOM AND DATA CODES (NEC STANDARD)

HOW TO SETUP IR CODES :

Model number : HD-44G
CUSTOM CODE : 837C

POWER ON : 837C A15E
POWER OFF : 837C A25D

ALL : 837C B04F
OFF : 837C B14E
EDID : 837C B748
LOCK : 837C B54A
RECALL : 837C B24D
MEMORY : 837C B44B
ENTER : 837C B34C

PRESS TV DESTINATION - # then PRESS AV SOURCE - #

DESTINATION #1 : 837C 10EF
DESTINATION #2 : 837C 20DF
DESTINATION #3 : 837C 30CF
DESTINATION #4 : 837C 40BF

SOURCE #1 : 837C 01FE
SOURCE #2 : 837C 02FD
SOURCE #3 : 837C 03FC
SOURCE #4 : 837C 04FB

For example;
Select Destination # 1 to show Source #1~4,

The IR Data Code list :
Destination # 1 , Source #1 837C 10EF 837C 01FE
Destination # 1 , Source #2 837C 10EF 837C 02FD
Destination # 1 , Source #3 837C 10EF 837C 03FC
Destination # 1 , Source #4 837C 10EF 837C 04FB

Press EDID Mode key :

Mode 1 : FSS 837C E01F
Mode 2 : H24-3D 837C E11E
Mode 3 : H24M-3D 837C E21D
Mode 4 : H36 837C E31C
Mode 5 : H36M 837C E41B
Mode 6 : H36-3D 837C E51A
Mode 7 : H36M-3D 837C E619

IR EXTENDER

IR RECEIVER:

1. ANI-100 IR 300M Receiver

Device

Cable (3C)

IR Receiver (ANI-100)

ANI-100 IR Receiver Set



ANI-100 Maximum Distance ~ 984 feet (300 meters)

2. ANI-100C IR 2M Receiver

Device

Cable (3C)

IR Receiver (ANI-100C)

IR Receiver cable 6ft (2M)

ANI-100C IR Receiver Cable



ANI-100C Maximum Distance ~ 6 feet (2 meters)

**** When you plug the External IR extender into the switcher, the front panel IR receiver remains active. ****

PIN CONFIGURATION:

ANI-100 and ANI-100C Receiver Pin configuration

ANI-100 IR Receiver Set

Tip: Signal
Ring :VCC
Sleeve: GND



ANI-100 Maximum Distance ~ 984 feet (300 meters)

IR Receiver cable 6ft (2M)

ANI-100C IR Receiver Cable

Tip: Signal
Ring: NC
Sleeve: GND



ANI-100C Maximum Distance ~ 6 feet (2 meters)

Note: *The External IR jack has voltage on the "Ring" portion of a 3-conductor plug. You must use a 3-conductor plug (aka: stereo plug). Using a 2-conductor plug will short out the power supply. Always make connections with the switcher power off.*

IR EXTENDER

IR EMITTER:

1. ANI-101 IR 300M Transmitter

Device | Cable (3C) | IR Transmitter (ANI-101)

ANI-101 IR Transmitter Set





ANI-101 Maximum Distance ~ 984 feet (300 meters)

---

2. ANI-101C IR 2M Transmitter

Device | Cable (3C) | IR Transmitter (ANI-101C)

IR Transmitter cable 6ft (2M)

ANI-101C Transmitter Cable





ANI-101C Maximum Distance ~ 6 feet (2 meters)

*** *When you plug the External IR extender into the switcher, the front panel IR transmitter remains active.* ***

PIN CONFIGURATION:

ANI-101 and ANI-101C Transmitter Pin configuration

ANI-101 IR Transmitter Set

Tip: Signal
Ring :VCC
Sleeve: GND





ANI-101 Maximum Distance ~ 984 feet (300 meters)

IR Transmitter cable 6ft (2M)

ANI-101C Transmitter Cable

Tip: Signal
Ring: NC
Sleeve: GND





ANI-101C Maximum Distance ~ 6 feet (2 meters)

Note: *The External IR jack has voltage on the "Ring" portion of a 3-conductor plug. You must use a 3-conductor plug (aka: stereo plug). Using a 2-conductor plug will short out the power supply. Always make connections with the switcher power off.*

EDID FUNCTION

EDID FUNCTION SETUP

EDID setup	To change the EDID setup
Step 1. Press the **EDID** button	The display will show the currently selected EDID mode
Step 2. Press **SOURCE** #1 or #2 button row	The button will flash blue and the display will show the current **Embedded EDID** Status.
Step 3. Press the **ENTER** button	To set **EDID** mode. The switcher will return to operation mode.
Operation will abort if no keys are pressed within 5 seconds.	

Embedded EDID modes	Total 7 EDID Modes
Embedded EDID setup Press **EDID** > **SOURCE** > **ENTER** SOURCE #1 or SOURCE #2 Select **Embedded EDID** : Mode 1 : FSS Mode 2 : H24-3D Mode 3 : H24-3D-M Mode 4 : H36-3D Mode 5 : H36-3D-M Mode 6 : DVI-D 1280x1024-60Hz Mode 7 : DVI-D 1920x1200-60Hz	To select **Embedded EDID** mode or **LEARNING** mode Press **EDID** button : The LCM will show the current EDID status. Repeatedly depressing the **source 1** button will cycle **up** thru the options. Repeatedly depressing the **source 2** button will cycle **down** thru the options.
LEARNING EDID	**Learning EDID from Destination to Source**
Learning EDID setup Press **EDID** > **DESTINATION** > **SOURCE** > **ENTER**	Press **EDID** > Switcher will LEARN destination EDID and pass the selected source. Press: **EDID > DESTINATION #1 >** Switcher will LEARN destination #1 EDID and pass the selected source.

NOTE : The already learned EDID cannot be modified. You can only rebuild a new Learning EDID.
For example: When the Source has “Learned” the EDID data from a destination, It will save that EDID information into EPROM and the EDID data cannot change. Please select new learning destination to sources or change to one of the embedded EDID modes when you want to remove the learning EDID memory from EPROM.

EDID FUNCTION

EDID function : 7x Embedded EDID Modes	
Mode 1. FSS® (Fast Speed Start) 	**Fast Speed Start** mode shortens the startup time of the switcher. Selecting this mode does not force the EDID setup to be cancelled. Users may first select one EDID mode from mode 2 to 3, and then select mode 1 for fast speed start.
Mode 2. H24-3D (1080p-24 bits) 	Video Support : All resolutions up to and including 1080p. Audio Support : PCM 2CH
Mode 3. H24-3D-M (1080p-24bits) 	Video Support : All resolutions up to and including 1080p. Audio Support : MAT(MLP) 7.1CH, PCM 2CH, One Bit Audio 2CH, AC-3 5.1CH, DTS 5.1CH, PCM 7.1CH, Dolby Digital + 7.1CH, DTS-HD 7.1CH
Mode 4. H36-3D (1080p-36 bits) 	Video Support : All resolutions up to and including 1080p. Audio Support : PCM 2CH
Mode 5. H36-3D-M (1080p-36 bits) 	Video Support : All resolutions up to and including 1080p. Audio Support : MAT(MLP) 7.1CH, PCM 2CH, One Bit Audio 2CH, AC-3 5.1CH, DTS 5.1CH, PCM 7.1CH, Dolby Digital + 7.1CH, DTS-HD 7.1CH
Mode 6. 1280x1024-60Hz (DVI-D) 	DVI Support : DVI-D 1280x1024 60Hz
Mode 7. 1920x1200-60Hz (DVI-D) 	DVI Support : DVI-D 1920 x 1200 60Hz

EDID FUNCTION

EDID FUNCTION : LEARNING

Learning EDID Single to Single	Example : Learn Destination #4 EDID To Source #3.
Step 1. Press the **EDID** button	The button will flash blue and the display will show the current **Embedded EDID** Status.
Step 2. Press the Destination #4 button row	Copy the Destination #4 Display EDID.
Step 3. Press the Source #3 button row	Learning the Destination #4 EDID To Source # 3.
Step 4. Press **ENTER** button	To confirm entries.
Learning EDID Single to multiple	**Learning destination EDID link to the majority Sources**
Step 1. Press the **EDID** button	The button will flash blue and the display will show the current **Embedded EDID** Status.
Step 2. Press the Destinations #1~4 button row	Copy any 1~4 Destinations EDID.
Step 3. Press the Source #1, #3, #4 button row	Learning the Destination EDID link to source #1, #3, #4.
Step 4. Press **ENTER** button	To confirm entries.
Learning EDID Single to ALL	**Learning destination EDID link to All Sources**
Step 1. Press the **EDID** button	The button will flash blue and the display will show the current **Embedded EDID** Status.
Step 2. Press destination button 1 thru 4	Learning anyone 1~4 Destination EDID to all sources.
Step 3. Press **ALL** button	Learning selected destination EDID to all sources.
Step 4. Press **ENTER** button	To confirm entries.
EDID status	**To view the current EDID status.**
Step 1. Press the **EDID** button	The button will flash blue and the display will show the current **Embedded EDID** Status.
Step 2. Press the **EDID** button	To exit.
How to setup FSS® Function	**Fast speed start®**
Step 1. Press the Destination #1~4 button row Then Press the Source #1~4 button row	To setup and Install all devices.
Step 2. Press the **EDID** button	Select a optimum status of **Embedded EDID** mode.
Step 3. Press **ENTER** button	To conform entries.
Step 4. Press the **EDID** button	To select the EDID **FSS®** mode.
Step 5. Press **ENTER** button	To conform entries.
LEARNING EDID definition	**Learning EDID from Destination to Source**

1. Switcher will **LEARN** destination EDID and pass the selected source.
2. To set up learning between a single destination and single source:
Press **EDID** button > Press **Destination** 1 thru 4 > Press Source 1 thru 4 > Press **ENTER** to confirm.
Switcher will learn destination EDID to source device.
3. To set up learning between a single destination and Multiple sources:
Press **EDID** button > Press **Destination** 1 thru 4 > Press the majority Sources 1 thru 4 > Press **ENTER**.
Switcher will learn single destination EDID to many source devices.
4. How to Learning single destinations with all sources. Press **EDID** button > Press **ALL** button > Press **ENTER** to confirm.

RS-232 SERIAL INTERFACE

RS-232 SERIAL INTERFACE CONNECT a PC or CONTROL SYSTEM. VERSION COMPATIBLE V2.0

Example of the commanded string to route Input 3 to Output 4
OUTPUT04 03;

RS-232 Configuration

RS-232 cable is a straight thru cable and not null-modem

HD-44G Device

Definition	Pin		Pin	Definition
	1		1	DCD
TX	2		2	RX
RX	3		3	TX
	4		4	DTR
GND	5		5	GND
	6		6	DSR
	7		7	RTS
	8		8	CTS
	9		9	RI

PC

RS-232 Pin Diagram



RS-232 SERIAL INTERFACE PROTOCOL COMMANDS (ETHERNET / RS-232 CONTROL DRIVER V2.0)

The HD-44G switcher can be controlled via the RS-232 serial control port to allow for interfacing to a PC, or similar third party control system.

The serial communication parameters are 9600 baud, 8 bit, No Parity and 1 stop bit - this is often referred to as 9600 8N1. When the unit recognizes a complete command it will perform the requested action - there is no delimiter character required.

ETHERNET SERIAL INTERFACE

ETHERNET SERIAL INTERFACE CONNECT A PC OR CONTROL SYSTEM. VERSION COMPATIBLE V2.0

For a complete list of commands, please reference external document extended Ethernet Protocol Instruction Manual.
Example of the commanded string to route Input 3 to Output 4
OUTPUT04 03;



Note :
Control the switcher
SPD : Speed
LINK : Ethernet link
RJ-45 Female 8P-8Cconnector

ETHERNET SERIAL INTERFACE

Pin	Ethernet	Reference
1	TXOP	TX +
2	TXON	TX -
3	RXIP	RX +
4	NC	
5	NC	
6	RXIN	RX -
7	NC	
8	GND	

ETHERNET TCP/IP PROTOCOL COMMANDS (Ethernet / RS-232 Control driver V2.0)

**** When Ethernet is used, the switcher will not accept commands from the RS-232 port. ****

TERMS AND CONDITIONS OF USE

PLEASE READ THE FOLLOWING TERMS AND CONDITIONS CAREFULLY BEFORE USING THIS HARDWARE, COMPONENTS AND SOFTWARE PROVIDED BY, THROUGH OR UNDER A-NeuVideo, INC (COLLECTIVELY, THE "PRODUCT"). By using installing or using the Product, you unconditionally signify your agreement to these Terms and Conditions. If you do not agree to these Terms and Conditions, do not use the Product and return the Product to A-NeuVideo, Inc. at the return address set forth on the Product's packing label at your expense. A-NeuVideo, Inc. may modify these Terms and Conditions at anytime, without notice to you.

RESTRICTIONS ON USE OF THE PRODUCT

It is your responsibility to read and understand the installation and operation instructions, both verbal and in writing, provided to you with respect to the Product. You are authorized to use the Product solely in connection with such instructions. Any use of the Product not in accordance with such instructions shall void any warranty pertaining to the Product. Any and all damages that may occur in the use of the Product that is not strictly in accordance with such instructions shall be borne by you and you agree to indemnify and hold harmless A-NeuVideo, Inc. from and against any such damage.

The Product is protected by certain intellectual property rights owned by or licensed to A-NeuVideo. Any intellectual property rights pertaining to the Product are licensed to you by A-NeuVideo, Inc. and/or its affiliates, including any manufacturers or distributors of the Product (collectively, "A-NeuVideo") for your personal use only, provided that you do not change or delete any proprietary notices that may be provided with respect to the Product.

The Product is sold to you and any use of any associated intellectual property is deemed to be licensed to you by A-NeuVideo for your personal use only. A-NeuVideo does not transfer either the title or the intellectual property rights to the Product and A-NeuVideo retains full and complete title to the intellectual property rights therein. All trademarks and logos are owned by A-NeuVideo or its licensors and providers of the Product, and you may not copy or use them in any manner without the prior written consent of A-NeuVideo, which consent may be withheld at the sole discretion of A-NeuVideo.

The functionality and usability of the Product is controlled by A-NeuVideo, Inc. from its offices within the State of Texas, United States of America. A-NeuVideo makes no representation that materials pertaining to the Product are appropriate or available for use in other locations other than the shipping address you provided with respect thereto. You are advised that the Product may be subject to U.S. export controls.

Disclaimers and Limitation of Liability

A-NeuVideo may change or modify the Product at any time, from time to time.

THE PRODUCT IS PROVIDED "AS IS" AND WITHOUT WARRANTIES OF ANY KIND EITHER EXPRESS OR IMPLIED. A-NEUVIDEO DOES NOT WARRANT OR MAKE ANY REPRESENTATIONS REGARDING THE USE OR THE RESULTS OF THE USE OF THE PRODUCT'S CORRECTNESS, ACCURACY, RELIABILITY, OR OTHERWISE.

A-NeuVideo has no duty or policy to update any information or statements pertaining to the Product and, therefore, such information or statements should not be relied upon as being current as of the date you use the Product. Moreover, any portion of the materials pertaining to the Product may include technical inaccuracies or typographical errors. Changes may be made from time to time without notice with respect to the Product.

TO THE FULLEST EXTENT PERMISSIBLE PURSUANT TO APPLICABLE LAW, A-NEUVIDEO DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT. A-NEUVIDEO DOES NOT WARRANT THE ACCURACY, COMPLETENESS OR USEFULNESS OF ANY INFORMATION WITH RESPECT TO THE PRODUCT. A-NEUVIDEO DOES NOT WARRANT THAT THE FUNCTIONS PERTAINING TO THE PRODUCT WILL BE ERROR-FREE, THAT DEFECTS WITH RESPECT TO THE PRODUCT WILL BE CORRECTED, OR THAT THE MATERIALS PERTAINING THERETO ARE FREE OF DEFECTS OR OTHER HARMFUL COMPONENTS. A-NEUVIDEO WILL USE ITS REASONABLE EFFORTS TO CORRECT ANY DEFECTS IN THE PRODUCT UPON TIMELY WRITTEN NOTICE FROM YOU NOT TO EXCEED 10 BUSINESS DAYS AFTER RECEIPT BY YOU OF THE PRODUCT, BUT YOU (AND NOT A-NEUVIDEO) ASSUME THE ENTIRE COST OF ALL NECESSARY SERVICING, REPAIR AND CORRECTION THAT WAS CAUSED BY YOU UNLESS OTHERWISE AGREED TO IN A SEPARATE WRITING BY A-NEUVIDEO.

UNDER NO CIRCUMSTANCES, INCLUDING, BUT NOT LIMITED TO, NEGLIGENCE, SHALL A-NEUVIDEO BE LIABLE FOR ANY SPECIAL OR CONSEQUENTIAL DAMAGES THAT RESULT FROM THE USE OF, OR THE INABILITY TO USE THE PRODUCT IN ACCORDANCE WITH ITS SPECIFICATIONS, EVEN IF A-NEUVIDEO OR ITS REPRESENTATIVES HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN NO EVENT SHALL A-NEUVIDEO'S TOTAL LIABILITY TO YOU FROM ALL DAMAGES, LOSSES, AND CAUSES OF ACTION (WHETHER IN CONTRACT, OR OTHERWISE) EXCEED THE AMOUNT YOU PAID TO A-NEUVIDEO, IF ANY, FOR THE PRODUCT.

END OF DOCUMENT